

# ONE-STEP

## ABRAZIVE SANDING-POLISHING PASTE

- Saves time – make all polishing steps with one product.
- Leaves no holograms.
- Does not contain wax and silicone.
- Suitable for electric and pneumatic polishing machines (900-2500 rpm).

We recommend an innovative, next generation polishing disc SOLL POLISHING SPONGE (red-white) for polishing each coating. Small cuts on the surface of the two-layered disc reduce the heating-up of the treated surface and the amount of rising dust.



## APPLICATION INSTRUCTIONS

1. Shake the bottle before use.
2. Apply the necessary amount of the paste to the polishing disc and spread evenly on the polished surface.
3. Start polishing by pressing on the surface with medium force until all the scratches are removed.
4. When the paste begins to dry, reduce your pressure force.
5. After completing the polishing, remove paste remains with a cloth.